

Hex codes sent by the Apollo DN300 KM keyboard				
1200bps 8 bits even parity				
	Press	Release	Shift	Control
	81	A1	91	*
	82	A2	92	*
	83	A3	93	*
	B0	B8	B4	*
	B1	B9	B5	*
	B2	BA	B6	*
	84	A4	94	*
	85	A5	95	*
	86	A6	96	*
	87	A7	97	*
	88	A8	98	*
	89	A9	99	*
	8A	AA	9A	*
	8B	AB	9B	*
	8C	AC	9C	*
	8D	AD	9D	*
	8E	AE	9E	*
	8F	AF	9F	*
	C0	E0	D0	F0
	C1	E1	D1	F1
	C2	E2	D2	F2
	C3	E3	D3	F3
	C4	E4	D4	F4
	C5	E5	D5	F5
	C6	E6	D6	F6
	C7	E7	D7	F7
	1B		1B	
	31		21	
	32		40	
	33		23	
	34		24	
	35		25	
	36		5E	
	37		26	
	38		2A	
	39		28	
	30		29	

—		2D		5F	
+ =		3D		2B	
~ \		60		7E	1E
BACK SPACE		DE		DE	
TAB		CA		DA	FA
Q		71		51	11
W		77		57	17
E		65		45	05
R		72		52	12
T		74		54	14
Y		79		59	19
U		75		55	15
I		69		49	09
O		6F		4F	0F
P		70		50	10
[		7B		5B	1B
]		7D		5D	1D
DELETE		7F		7F	
CTRL					
CAPS LOCK					
A		61		41	01
S		73		53	13
D		64		44	04
F		66		46	06
G		67		47	07
H		68		48	08
J		6A		4A	0A
K		6B		4B	0B
L		6C		4C	0C
;		3B		3A	
'		27		22	
RETURN		CB		DB	FB
/ \		C8		C9	F8
REPEAT					
SHIFT					
Z		7A		5A	1A
X		78		58	18
C		63		43	03
V		76		56	16
B		62		42	02
N		6E		4E	0E
M		6D		4D	0D
<		2C		3C	

> .		2E		3E	
? /		CC		DC	FC
SHIFT					
POP		80	A0	90	*
		20		20	00
AGAIN		CD	ED	E9	*
READ		CE	EE	EA	*
SAVE EDIT		CF	EF	EB	*
ABORT EXIT		DD	FD	EC	*
HELP HOLD		B3	BB	B7	*
* = no press code is sent only the release code					
Empty means that no code is sent.					